

# ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way  
Paso Robles, CA 93447  
Telephone: (800) 350-2223 Fax: (805) 238-4201

P/N: 27-0044T

PAGE 1 OF 1  
Page Rev. Date: 11-11-20

## BRONCO DANA 20/ 29 SPLINE NV4500 TRANS.

### KIT CONSISTS OF:

No.	Qty	Part No.	Description
1.	1	716107C	*CHEVY 11" DISC.
2.	1 Kit	50-0230	4WD 29 SPLINE NV4500 TO BRONCO DANA 20 T/C
3.	1 Kit	712551	DODGE NV4500 TO FORD V8 BHSG.
4.	1 Kit	716050D1	NV4500 SHIFT HANDLE ASSY.
5.	1 Kit	716101-2	NV4500 MOUNTING PLT. KIT BRONCO

### INSTALLATION NOTES:

This kit is designed to fit the Dodge Standard Duty NV4500 transmission.

This kit requires the use of a stock Ford bellhousing with a 4.848" index diameter.

This is a parts pull sheet. Refer to the instruction sheet on each kit for proper installation.

**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.