

# ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

# P/N: 716116

PAGE 1 OF 1

Page Rev. Date: 03-14-16

## SLAVE CYLINDER ASSEMBLY FOR 716118 MASTER CYLINDER

### KIT CONSISTS OF:

| No. | Qty | Part No. | Description                      |
|-----|-----|----------|----------------------------------|
| 1.  | 2   | 716039   | SLAVE CYLINDER SPACERS           |
| 2.  | 1   | 716116R  | PUSH ROD                         |
| 3.  | 1   | 716116S  | SLAVE CYLINDER                   |
| 4.  | 1   | 716130H  | 42" HYD. HOSE AND (1) #3 FITTING |
| 5.  | 2   | 716130F  | #3 MASTER CYLINDER FITTING       |
| 6.  | 1   | 716139   | GM WEDGE                         |
| 7.  | 2   | 723735   | 3/8" WASHER                      |
| 8.  | 2   | 723704   | 3/8" LOCKWASHER                  |
| 9.  | 2   | 723719   | 3/8"-24 JAM NUT FOR PUSH ROD     |
| 10. | 2   | 723725   | 3/8"-16 x 2" H.H.C.S.            |



The two spacers bolt between the slave cylinder and the bracket to space the slave cylinder properly from the bracket and to locate the bleeder in a upward position.



**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.