

ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

P/N: 716119

PAGE 1 OF 1

Page Rev. Date: 11-17-11

SLAVE CYLINDER ASSEMBLY

KIT CONSISTS OF:

No.	Qty	Part No.	Description
1.	1	716119H1	STAINLESS STEEL SLAVE CYLINDER HOSE 24"
2.	1	716119S	SLAVE CYLINDER
3.	1	716139	GM WEDGE
4..	2	723719	3/8"-24 JAM NUT FOR PUSH ROD
5.	1	723759	3/8"-24 x 6" ALL THREAD

This Toyota slave cylinder is designed to fit our bracket Part Numbers 716287 or 716288. The slave cylinder comes with two push rod options. The gold colored rod should be used on GM stamped steel arms, and the all thread and wedge should be used on GM cast iron arms.

SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.