

# CLUTCH SLAVE CYLINDER & BRACKET FOR GEN. III V8'S W/ TRUCK MANIFOLDS

## KIT CONSISTS OF:

No.	Qty	Part No.	Description	<u>Optional items</u>
1.	1	716286-BLK	BRACKET ASSEMBLY	This slave cylinder bracket is designed to fit our slave cylinder, P/N 716213
2.	1	716139	FORK WEDGE	
3.	1	716215	SLAVE CYLINDER FITTING	
4.	1	720015	10mm FLAT WASHER (spacer - lower bolt hole bracket to block)	
5.	2	723704	3/8" LOCK WASHERS	
6.	2	723705	3/8"-24 JAM NUTS	
7.	2	723725	3/8"-16 x 1-3/4" H.H.C.S.	
8.	1	723771	3/8"-24 x 9" ALL THREAD <i>(Before shipping, all thread must have radius' on both sides)</i>	

## INSTALLATION INSTRUCTIONS:

This bracket is designed for use on the GEN. III Vortec V8s. This slave cylinder bracket should only be used with our NV4500 full bellhousings. The slave cylinder location is close to the exhaust port of the Vortec engine so we recommend some type of heat shield to be made and installed around the slave cylinder.

The metric washer must be installed between the bellhousing and the bracket lower hole. This washer is a spacer because the bellhousing is spot-faced on that lower hole location.



**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.