

# **ADVANCE ADAPTERS, INC.**

P.O. Box 247, 4320 Aerotech Center Way  
Paso Robles, CA 93447  
Telephone: (800) 350-2223 Fax: (805) 238-4201

## **P/N: AS-8610**

PAGE: 1 OF 1  
Page Rev. Date: 02-07-13

## **ATLAS SPACER ADAPTER**

### **KIT CONSISTS OF:**

<b>No.</b>	<b>Qty.</b>	<b>Part No.</b>	<b>Description</b>
1.	1	51-8610	1/2" ADAPTER RING
2.	6	723701	3/8"-16 HEX NUT
3.	6	723704	LOCK WASHER
4.	6	723710	STUD BOLT 3/8"-16 x 2-3/4" LG.

Note: This spacer will not work on a New Process transfer case as it interferes with the retainer bolts, if a spacer is needed please use the 3/4" one AS-8603

**SPECIAL NOTE:** The components packaged in this kit have been assembled and machined for specific types of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand the modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This Instruction Sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque vales, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.