

ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

P/N: 716130TJH

PAGE 1 OF 1

Page Rev. Date: 07-17-12

JEEP TJ SLAVE CYLINDER HOSE REPLACEMENT

KIT CONSISTS OF:

No.	Qty	Part No.	Description
1.	1	716130H	42" HYD. HOSE
2.	2	716130TJ	TJ MASTER CYLINDER FITTING & SLAVE CYLINDER FITTING

INSTRUCTIONS:

This new slave hose comes with two pin-type fittings that connect to the stock TJ master cylinder and the slave cylinder. To remove the old slave cylinder hose, locate the roll pin on both the master cylinder and slave cylinder. Remove the pin, and the hose should slide out. The rubber o-ring must be retained and installed onto the new brass fitting. The new fitting can then be installed back into the master cylinder and slave cylinder and then be retained with the roll pin.

The hose assembly must be bled to remove any air operation of the vehicle. We recommend that you remove the master cylinder cap and slowly depress the clutch. After several depressions, the hose assembly should be bled and the slave cylinder should be operational. Refill the master cylinder and replace the cap.

SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.