

ADVANCE ADAPTERS INC.

P.O. Box 247, 4320 Aerotech Center Way

Paso Robles, CA 93447

Telephone: (800) 350-2223 Fax: (805) 238-4201

P/N: 715600

PAGE 1 OF 1

Page Rev. Date: 01-22-16

4 SPEED SHIFTER ASSEMBLY WITHOUT LINKAGE RODS(HURST SHIFTER BODY)

KIT CONSISTS OF:

No.	Qty	Part No.	Description
1.	1	715647	BODY, HANDLE & HARDWARE KIT
2.	1	715644	OFFSET HANDLE
3.	1	715648	KNOB
4.	1	723719	HEX JAM NUT 3/8 -24 PLATED

INSTALLATION INSTRUCTIONS:

1. Align levers with shifter frame and insert neutral **alignment rod**.
2. Adjust position of button on each rod to permit easy slip-in fit of button into nylon bushings in proper lever. **Transmission arms must remain in neutral position while aligning is being performed.** Fasten buttons in levers with spring clips.
3. Remove neutral alignment rod. Test shifter. Stick should move freely from side to side at neutral (between 1-2 & 3-4 shifting paths). An increased pull towards the operator should engage the reverse lever.
5. Adjust shifter stop bolts. Back bolts out of shifter frame into 3rd gear and hold. Screw in 3rd gear stop bolt until contact is felt. Back out bolt one turn and tighten lock nut. Pull stick firmly back into 4th gear, screw in 4th gear stop bolt until contact is made, then back stop bolt one turn and tighten lock nut.

The Hurst shifter comes with a new handle, however, the handle is short and sets of to the side of the transmission. This location may or may not work for your vehicle application. We have included one of our offset handles that is longer and offers a offset of 3" on it to bring the shifter up through the center of the floorboard..

SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.