



P.O. Box 247, 4320 Aerotech Center Way
Paso Robles, CA 93447
Telephone: (800) 350-2223 Fax: (805) 238-4201
PAGE 1 OF 1 Page Rev. Date: 09-05-21
P/N: 302010 & 302011

ATLAS BAGGED HARDWARE KIT (302010) ATLAS BOOT & KNOB KIT (302011)

KIT 302010 CONSISTS OF:

No.	Qty	Part No.	Description
1	2	303055	ROD END- ATLAS SHIFT SHAFT
2	1	303070	PIVOT TOWER- ATLAS TWIN STICK
3	4	303081	Bushing - Igus 1/2" X 1/2"
4	2	303085	BOLT- SHOULDER FOR ATLAS SHIFTER BLOCK
5	4	303096	IGUS SMALL NYLINER
6	4	303110	BUTTON SHIFTER
7	4	303115	E CLIP RETAINER
8	1	303120	Serrated-Flange Hex Locknut 1/2"- 13 zinc
9	4	722546	SCREW-TEK, HEX SELF DRILLING W/NEO #10- 16 X 1"
10	3	723731	S.H.C.S. 3/8"-16 X 1" ZINC

KIT 302011 CONSISTS OF:

No.	Qty	Part No.	Description
1	1	302060	BOOT- TWIN STICK
2	2	302061	ATLAS KNOB STICKERS
3	1	302062	STICKER - ATLAS SHIFTER L-N-H
4	2	302083	KNOB- ATLAS SHIFTER
5	1	302063	BOOT RING- ATLAS TWIN STICK

SPECIAL NOTE: The components packaged in this kit have been assembled and machined for specific type of conversions. Modifications to any of the components will void any possible warranty or return privileges. If you do not fully understand modifications or changes that will be required to complete your conversion, we strongly recommend that you contact our sales department for more information. This instruction sheet is only to be used for the assembly of Advance Adapter components. We recommend that a service manual pertaining to your vehicle be obtained for specific torque values, wiring diagrams and other related equipment. These manuals are normally available at automotive dealerships and parts stores.